Supported Hardware

A firmware update may be required to enable advanced haptics

Touchpad

- ASUS ProArt P14 (H7407)
- ASUS ProArt P16 (H7607)
- ASUS ExpertBook A7 (A7406CMA)
- Surface Laptop 8
- Surface Laptop Ultra

Mouse

- Logitech MX Master 4
- Surface Mouse (2nd Edition)

Stylus

- ASUS Pen 3.0
- Surface Slim Pen 2
- MSI Pen 2

Supported Apps

An app update may be required to enable advanced haptics

- Adobe Photoshop (beta)
- Adobe Premiere
- Affinity
- Concepts
- DaVinci Resolve
- Filmora
- PowerPoint
- ProtoPie
- Sensory Studio